


PUSHLITE

LIT BELL PUSH | BELEUCHTBAR TASTER | LUMINEUX BOUTON
POUSSOIR | LUMINOSO PULSADOR DE TIMBRE

- EN Getting started DE Erste Schritte FR Démarrage NL Aan de slag FI Aloitusopas DK Kom i gang
IT Operazioni preliminari ES Para empezar PT Para começar GR Πρώτα βήματα SE Kom igång

D723W



ATTENTION!	
	—
	✓

8V 2A



- EN Trouble shooting DE Fehlerbehebung FR Dépannage NL Probleemoplossing FI Vianmääritys
DK Problemløsning IT Risoluzione dei problemi ES Solución de problemas PT Resolução de problemas
GR Αντιμετώπιση προβλημάτων SE Felsökning

livewell.honeywell.com